

MEMBER
ABYC
Setting Standards for Safer Boating

77

SEVENTY SEVEN
ISO 9001

OPTIMUS EPS
BY SEASTAR

BAYSTAR[™]

SEASTAR[™]

INSTALLATION MANUAL

ELECTRONIC SHIFT & THROTTLE (EST)

www.seastarsolutions.com



i7700 / i7800 Shift & Throttle System



SEASTAR
SOLUTIONS[®]

*Before you do it your way,
please try it our way*

©2017 SeaStar Solutions.

All Rights Reserved. This document, subject matter and all information herein is the sole, exclusive and confidential property of SeaStar Solutions and shall not be disclosed, copied, reproduced or used in whole or in part for any purpose other than as specifically authorized in writing by Marine Canada Acquisition (DBA SEASTAR SOLUTIONS).

All information, illustrations and specifications in this manual are based on the latest information available at the time of publishing. The illustrations used in this manual are intended as representative reference views only. Moreover, because of our continuous product improvement policy, we may modify information, illustrations and/or specifications to explain and/or exemplify a product, service or maintenance improvement. We reserve the right to make any change at any time without notice.



is a registered trademark of the American Boat & Yacht Council (<http://www.abycinc.org>)

NMEA 2000® is a registered trademark of the National Marine Electronics Association.

Optimus, Optimus 360, SeaStar, and BayStar are all trademarks of SeaStar Solutions.

**California
Proposition 65 Warning**

Battery posts, terminals, and related accessories contain lead and lead compounds, chemicals known to the state of California to cause cancer and reproductive harm.

Wash hands after handling.

Thank you for choosing an i7X00 Electronic Shift and Throttle (EST) System. You have chosen a state of the art shift and throttle system that will provide years of effortless and trouble free performance.

About this Book

This book contains the information required to install and setup the i7X00 EST System.

It is to be delivered to the customer when installation is complete.

Notice to the Installer

Throughout this publication, Dangers, Warnings and Cautions (accompanied by the International Hazard Symbol ) are used to alert the user to special instructions concerning a particular service or operation that may be hazardous if ignored or performed incorrectly or carelessly. **Observe Them Carefully!**

These safety alerts alone cannot eliminate the hazards that they signal. Strict compliance with these special instructions during installation, operation, and maintenance, plus common sense operation, are important measures to prevent accidents.

DANGER

IMMEDIATE HAZARDS WHICH, IF NOT ACTED UPON, WILL RESULT IN SEVERE PERSONAL INJURY OR DEATH.

WARNING

HAZARDS OR UNSAFE PRACTICES WHICH, IF NOT ACTED UPON, COULD RESULT IN SEVERE PERSONAL INJURY OR DEATH.

CAUTION

Hazards or unsafe practices which COULD result in minor injury or product or property damage.

NOTICE

Information which is important to proper use or maintenance, but is not hazard-related.

This page left intentionally blank.

INDEX

1.0	Safety	1-1
1.1	Safety Labels	1-3
2.0	System Overview.....	2-1
2.1	System Description.....	2-1
2.2	System Overview Diagram	2-2
3.0	Installation	3-1
3.1	Important Information/Technical Support Contact	3-1
3.2	Installing the Control Head	3-1
3.2.1	<i>Control Head Trim Switch Connection</i>	3-1
3.3	Installing the Actuators	3-3
3.3.1	<i>Location and Identification</i>	3-3
3.3.2	<i>Mounting</i>	3-3
3.3.3	<i>Mechanical Cables</i>	3-3
3.4	Electrical Connections.....	3-4
3.4.1	<i>Power Connection</i>	3-4
3.4.2	<i>Start-in-Gear Protection</i>	3-4
3.4.3	<i>Ignition Source</i>	3-5
3.5	CAN2 Harness Connections.....	3-6
3.6	Analog Tachometer	3-9
3.6.1	<i>NMEA Gateway Connection</i>	3-10
4.0	System Setup	4-1
4.1	Actuator Setup	4-1
4.1.1	<i>Actuator Configuration</i>	4-1
4.1.2	<i>Actuator Adjustment</i>	4-4
4.1.2.1	<i>Shift Adjustment</i>	4-4
4.1.2.2	<i>Shift Adjustment</i>	4-5
4.2	Control Head Setup	4-6
5.0	Sea Trial	5-1
5.1	Shift Performance.....	5-1
5.2	Throttle Performance	5-1
5.3	Control Head Adjustments.....	5-1
5.4	Conclusion of Sea Trial.....	5-2
6.0	System Faults & Hazards.....	6-1
6.1	Hazard Definitions	6-1
6.1.1	<i>Danger</i>	6-1
6.1.2	<i>Warning</i>	6-1
7.0	Warranty	7-1
7.1	Statement of Limited Warranty	7-1
7.2	Return Goods Procedure	7-1
7.3	Technical Support.....	7-1

Appendix A – Mounting Templates	A-1
A.1 Control Head – Dual Lever.	A-1
A.2 Control Head – Single Lever.....	A-2
A.3 Actuator – Dimensions.	A-3
A.4 Single Lever Interface – Dimensions.....	A-3
Appendix B – Using the Color CANtrak Display	B-1
B.1 Display Navigation	B-1
B.2 Initial Startup	B-2
B.4 Unlocking the Dealer Menu.....	B-2
B.4 Menu Structure	B-3
B.5 First Time Service Tool Users	B-4
Appendix C – Setup with Datalink	C-1
C.1 Dealer Tools	C-1
C.2 Connection.....	C-1
C.3 Navigating Datalink	C-3
C.4 Actuator Setup	C-5
C.4.1 Step 1 – Actuator Configuration Using Datalink	C-5
C.4.2 Step 2 – Cable Installation and Adjustment	C-7
C.4.3 Step 3 – Final Setup and Actuator Adjustment	C-7
C.5 Control Head Setup	C-9
Appendix D – Updating Firmware	D-1
D.1 Checking Component Firmware Revision Levels.....	D-2
D.1.1 Using DATALINK.....	D-2
D.2 Updating Actuators and Control Head.....	D-3
D.3 Updating the CANtrak Software.....	D-4

1.0 SAFETY INFORMATION

⚠ WARNING

THE SAFETY INFORMATION PROVIDED HERE IS INTENDED TO INFORM YOU OF THE DANGERS THAT MAY BE PRESENT BEFORE, DURING, AND AFTER INSTALLATION. IT IS CRITICAL THAT YOU READ AND UNDERSTAND THIS INFORMATION.

Safe operation of the shift and throttle system depends upon proper installation and maintenance of the system, and the common sense, safe judgment, knowledge, and expertise of the operator. Every installer and operator of the i7X00 system should know the following requirements before installing or operating the system. If you have any questions regarding any of these warnings, contact SeaStar Solutions.

Before installation

1. Read and understand all installation and user's manuals provided with the i7X00 components.
2. Ensure that all components required to complete the installation are on hand (including cables, harnesses, and the proper tools).
3. SeaStar and i7X00 components are highly engineered and safety tested to ensure system integrity. DO NOT substitute any component. Substitution with non-SeaStar or non-i7X00 components may compromise system safety, performance, and reliability.

During Installation

1. Install system components as directed in this manual. Some component parts and kits may be supplied with additional installation instructions—refer also to these instructions.
2. SeaStar and i7X00 components are highly engineered and safety tested to ensure system integrity. DO NOT substitute any component. Substitution with non-SeaStar or non-i7X00 components may compromise system safety, performance, and reliability.
3. If an instruction is unclear, contradictory, or you are otherwise uncertain how to proceed, do not guess. Call SeaStar Solutions technical support.

After Installation

1. Check that there is no interference between the control head levers and the steering wheel or any other dash-mounted components.
2. Operate the trim/tilt switch on the control head lever and verify that the engines tilt in the expected direction.
3. Check that the mechanical cable bends are smooth and have an appropriate minimum radius.

Prior to every use

Perform a system inspection as outlined below.

1. Check steering fluid level.
2. Verify immediate steering response when turning steering wheel(s).
3. Inspect all steering hoses, fittings, mechanical cables, and electrical harnesses for wear, kinks, or leaks.
4. Check for binding, loose, worn or leaking steering or shift/throttle control components.
5. Verify proper shift and throttle response for all control handles.

⚠ WARNING

DO NOT OPERATE BOAT IF ANY COMPONENT IS NOT IN PROPER WORKING CONDITION.

During use

1. WEAR A COAST GUARD-APPROVED PERSONAL FLOTATION DEVICE (PFD).
2. ATTACH ENGINE SHUT-OFF CORD (LANYARD) TO YOUR PFD.
3. Never allow anyone who is not familiar with the operation of the shift and throttle system to operate the boat at any time.
4. If boat is equipped with multiple helms, ensure that only one is used at a time.
5. Know and adhere to all applicable federal, state, and municipal laws and regulations that govern boating in your area.

⚠ WARNING

DO NOT OPERATE BOAT IF ANY COMPONENT IS NOT IN PROPER WORKING CONDITION.

After use

The i7X00 system requires no special attention after use. Periodically clean the control head with a damp cloth or mild soap. DO NOT use acetone, or cleaners containing ammonia, acids, or any other corrosive ingredients.

⚠ WARNING

FAILURE TO COMPLY WITH ANY WARNING, NOTICE OR CAUTION MAY LEAD TO LOSS OF STEERING OR SHIFT/THROTTLE CONTROL RESULTING IN A COLLISION AND/OR EJECTION FROM THE BOAT LEADING TO PROPERTY DAMAGE, PERSONAL INJURY AND/OR DEATH.

1.1 Safety Labels

⚠ WARNING

THE LABELS BELOW SHOULD CALL ATTENTION TO THE POSSIBLE HAZARDS ASSOCIATED WITH THE EQUIPMENT SHOWN LATER IN THIS MANUAL.

Component labels

The labels shown below are found on the i7X00 actuators.



SEASTAR SOLUTIONS
RICHMOND, BC, CANADA

AC7700 ACTUATOR

IGNITION PROTECTED
ISO 8846-MARINE
SAE J1171

ISO 25197
ABYC CE
seastarsolutions.com

SEASTAR™

MANUAL OVERRIDE OPERATION

Using the actuator override system may severely limit your boat's control. It should be used in an emergency if you are unable to call for assistance. Always try alternative controlling devices. Proceed with extreme caution, read User's Manual, always wear a PFD and lanyard.

1. Leave engine running. DO NOT key off when attempting to engage manual override. Allow actuator to remain in disabled state. DO NOT operate controls while attempting to manual override. Crank mechanism poses pinch hazard at all times.
2. Remove cover.
3. On **SHIFT** control mechanism, remove cotter pin and slide eye terminal off post. Pull or push control cable into desired gear.

4. Confirm desired gear is engaged before applying throttle.
5. On **THROTTLE** control mechanism, remove cotter pin and slide eye terminal off post.
6. Very slowly pull or push control cable to increase '+' rpm. No more than 1" or 25mm should be required.
7. Key off ignition to slow and stop vessel.

NOTICE

U.S. Coast Guard requires start-in-gear protection. If your engine does not have this feature, this control system will provide start-in-gear protection meeting U.S.C.G. requirements of 33 CFR part 183, sub part 1. Consult Installation Manual.

Assembled in China for SeaStar Solutions 277045

⚠ WARNING

Install and maintain in accordance with SeaStar Solutions Installation Manual. Secure all connections. Failure to comply with above may result in loss of vessel control, leading to possible ejection from vessel causing property damage, personal injury and/or death.

Figure 1-1. Actuator decal, PID# 277045.

STARBOARD ENGINE THROTTLE		STARBOARD ENGINE THROTTLE		
STARBOARD ENGINE SHIFT		STARBOARD ENGINE SHIFT		
CENTER ENGINE THROTTLE		CENTER ENGINE THROTTLE		R
CENTER ENGINE SHIFT		CENTER ENGINE SHIFT		
PORT ENGINE SHIFT		PORT ENGINE SHIFT		F
PORT ENGINE THROTTLE		PORT ENGINE THROTTLE		
STARBOARD		PORT		IDLE
				+

Figure 1-2. Actuator decal sheet, PID# 277044.

This page left intentionally blank.

2.0 SYSTEM OVERVIEW

2.1 System Description


SeaStar i7X00 is an electromechanical system that replaces a traditional cable-operated engine remote control with an electronic control. Shift and throttle settings are sent over a serial data network to electro-mechanical actuators, where they are converted to cable motion. The elimination of mechanical cables to the control head simplifies multi-station installations, especially when a station is installed onto a flybridge or tower that is removed for shipping. The system supports the installation of up to three control heads.

The i7X00 system consists of the major components listed below.

CAN Network


CAN (controller area network) is a serial network protocol that is widely used in marine and automotive control systems. Each device (node) on the network can send and receive data using specially formatted messages. The ability to reliably communicate data between devices is what enables the functionality of i7X00.

i7X00 implements the high-speed CAN protocol using DeviceNet harnesses and connectors. We refer to the network as CAN2 in the documentation to distinguish it from other CAN protocols used on SeaStar products.



Control Head


The control head looks much like a conventional mechanical remote control, but it is an electromechanical device that converts lever position into digital messages that are sent over CAN2 to the shift and throttle actuators. The control head features adjustable lever feel, status lights, a synchronous trim switch (optional), and control buttons for added functionality.



Shift and Throttle Actuator

The actuators are electromechanical devices that receive digital commands on the CAN2 network and convert these commands into movement of a mechanical cable for gear selection and throttle control. The actuators are universal, and are easily setup for their specific application using the CANtrak display tool. They can also provide the start-in-gear protection required by the U.S. Coast Guard.

2.2 System Overview Diagram



1. Control Head
2. Throttle/Shift Actuator
3. CAN Network Bus

Figure 2-1. System Overview.

3.0 INSTALLATION

3.1 Important Information/Technical Support Contact

To assist with the installation and maintenance of this Electronic Shift and Throttle system SeaStar Solutions recommends that:

- Installation MUST be performed by a SeaStar Solutions authorized installer.
- Read and understand ALL installation manuals before starting the installation process. Knowing the correct order of installation and location of components will drastically reduce installation time as well as prevent common installation errors.
- Read and understand ALL Safety Information that is noted in this manual and ALL other Installation Manuals.

If any problems are found before, during or after the installation of the steering system, please contact Technical Support for assistance:

Technical Support

Web: www.seastarsolutions.com

E-mail: seastar@seastarsolutions.com

Phone: 604.248.3858

Fax: 604.279.2202

3.2 Installing the Control Head

Mount the control head on the dash in an area which will allow for convenient access during use. Whenever possible, it should be mounted in a location to minimize water spray. Ensure that the control handle(s) can be moved throughout the complete range of motion in both forward and reverse without interference. ABYC standard P-14 calls for a minimum of 2-1/2" (64 mm) clearance between the control lever and the steering wheel rim under all possible lever and wheel positions.


The control head requires one of the dash cutout templates in Appendix A.

3.2.1 Control Head Trim Switch Connection (Optional)

The control head includes a single trim/tilt switch on the end of the port handle. This switch can be wired to provide synchronous trim/tilt control of all engines. If independent trim/tilt is desired use tilt/trim kit HA5491 (for twin engine configurations) and connect the wiring as shown in Figure 3-1.

⚠ WARNING

ALL ELECTRICAL CONNECTIONS AND HARNESS MUST COMPLY WITH ABYC WIRING STANDARDS, BE RATED FOR 105°C (221°F), AND COMPLIANT WITH SAEJ1128.



WIRE COLOR LEGEND

TRIM UP	BLUE	=====
TRIM DOWN	GREEN	=====
POWER	RED	=====




Figure 3-1. Trim switch wiring.

3.3 Installing the Actuators

3.3.1 Location and Identification

Consider the following when locating and mounting the actuators:

- The mechanical cable run should be as short, straight, and direct as possible.
- The mechanical cables need adequate clearance where they exit the actuators and enter the engines. Be aware of the minimum bend radius of the cables you are using.
- The mounting location should be as dry as possible.
- The actuators require power and network connections.
- The actuators need to be accessible for emergency manual override. This means that the cover should be easily removed and the actuator identification decals must be clearly visible.

The actuators are configured identically from the factory so they can be used on either the port or the starboard engine. You will assign the identity of each actuator later when you configure the actuators. Note the serial numbers of the actuators and the engine side they control.

Actuator	Serial Number
Port	
Starboard	

Table 3-1. Actuator serial numbers.

3.3.2 Mounting

The actuator chassis has mounting holes on three surfaces to make it easy to orient and mount. (See page A-3 for mounting dimensions.) Use one of the following fastening methods:

- M6 machine screws with nuts and washers
- M6 machine screws into a threaded metal mounting surface
- #12 or #14 wood screws

Use four fasteners for each actuator. If you're mounting to an uneven surface it may be necessary to shim some mounting points to prevent twisting of the actuator chassis when the fasteners are fully tightened.

3.3.3 Mechanical Cables

Once you have located and mounted the actuators you can rough in the mechanical cables, but don't make any connections at this time. The decal sheet included with each actuator contains labels to identify the cable by engine and function. Label the cables at both ends to simplify the cable installation later.

We recommend SeaStar Xtreme cables, P/N CCX633xx. These cables have a minimum bend radius of 8".

NOTICE

Do not connect cables to the actuators at this time.

3.4 Electrical Connections

3.4.1 Power Connection

The actuator harness contains 6' leads for power connection.

1. Connect the black wire to the battery ground, either directly to the battery terminal or to a ground bus.
2. Connect the red wire to a 12VDC source through a 20A circuit breaker or fuse. The preferred source is the engine battery or a battery switch.

If you need to extend the leads, follow ABYC codes and practices. SeaStar Solutions recommends a minimum wire size of 10AWG. See the schematic wiring diagram (figure 3-9).

3.4.2 Start-in-Gear Protection

The US Coast Guard requires start-in-gear protection to prevent an engine from starting when forward or reverse gear is engaged. If your engine doesn't already have this feature, the i7X00 actuator can provide start-in-gear protection that meets the requirements of 33CFR part 183, subpart L.

If your engine already has start-in-gear protection it is recommended to connect the i7X00 actuator's start-in-gear protection switch for redundancy. This will also provide a redundant ignition source to the actuator in the event of an ignition source failure.

To use the start-in-gear protection intercept the start wire between the ignition switch and the engine start solenoid and connect the actuator switch leads as follows:

Yellow: Connect to ignition switch

Yellow with red tracer: connect to engine start solenoid.

NOTICE

The polarity of the start-in-gear protection connections is important. Do not reverse the leads.

Table 3-2 lists the ignition start system wire colors typically used by the major outboard manufacturers. This table is a guide only; always consult the manufacturer's documentation for correct wire identification.

NOTICE

Cap and tie back the leads if you do not need to use the actuator's start-in-gear protection.

Manufacturer	Wire Colors
Yamaha	Start circuit – brown
Suzuki	Short the brown wires together
Evinrude	Start circuit – yellow/red
Mercury	Start circuit – yellow/red

Table 3-2. Start system wire colors.

3.4.3 Ignition Source

The actuator harness contains a violet (purple) ignition lead. Connect this to the ignition switch for the engine the actuator is controlling. The wire should have 12VDC when the engine is switched on.

Option 1 – single ignition source




Figure 3-2.

Option 2 – splice into an existing engine ignition wire




Figure 3-3.

3.5 CAN2 Harness Connections

Figure 3-4 and figure 3-5 show the CAN2 network wiring for single and dual station applications. All tees *must* be secured using both screw holes, and the cable drops at each tee must be appropriately secured and strain-relieved to prevent any pull on the tees. See figure 3-6 for proper tee installation example.

The CAN2 network must contain two, and only two, terminating resistors. One terminator should be installed at each end of the network backbone.

⚠ WARNING

FAILURE TO SECURE HARNESS MAY RESULT IN HARNESS WEAR, CAUSING LOSS OF THROTTLE CONTROL, PROPERTY DAMAGE, PERSONAL INJURY AND/OR DEATH.




Figure 3-4. CAN2 wiring diagram, triple station, twin engine.




Figure 3-5. CAN2 wiring diagram, triple station, single engine.

⚠ WARNING

FAILURE TO SECURE HARNESS MAY RESULT IN HARNESS WEAR, CAUSING LOSS OF THROTTLE CONTROL, PROPERTY DAMAGE, PERSONAL INJURY AND/OR DEATH.

TIP: Once you've tightened the nuts on the tees, mark them with a permanent marker as shown in figure 3-6. This makes it easy to inspect them for tightness later.




Figure 3-6. Correct CAN2 tee installation example.

⚠ CAUTION

Do not connect anything other than SeaStar components to the CAN2 network.




Figure 3-7. Alternative CAN2 6-port hub connection (available separately).

3.6 Analog Tachometer

The actuator harness contains a gray lead that can be connected to an analog engine tachometer. You will not need to make this connection if you are getting the speed source through an NMEA2000 network, or if you have made an analog tachometer connection on the PCM CAN2 harness. See section 6.5 in Book 50 for more information on engine speed source selection and wiring.




Figure 3-8. Actuator harness wiring schematic.

3.6.1 NMEA Gateway Connection

Do not use an existing gateway connected to an existing NMEA 2000 network. The CAN2 network is not NMEA 2000 compliant, and there is a risk that an otherwise minor failure on the NMEA 2000 bus could interfere with the EST operation.

Connect the NMEA 2000 gateway to the engine bus and to a tee on the CAN2 network as shown in figure 3-9.

⚠ WARNING

ALTHOUGH BOTH NETWORKS USE COMPATIBLE CONNECTORS, DO NOT CONNECT THE I7X00 NETWORK TO A PUBLIC NMEA 2000 BUS.




Figure 3-9. NMEA gateway connection.

4.0 SYSTEM SETUP

For FIRST TIME USERS of the setup tool: Refer to Appendix B (page B-1) for startup instructions and then return to this section to proceed with setup.

Before you proceed you need to have all i7X00 components installed, harnesses connected, and power wiring completed. The actuator cables should *not* be connected yet.

This section will describe the system setup using the color CANtrak display as a setup tool (P/N EPSK1207). If you prefer to use Datalink you can find instructions in Appendix C.

If you are using the tachometer input on the actuator harness (section 3.6) you will need to select **i7X00 Tach** as the RPM Source from the System Setup menu.

4.1 Actuator Setup

4.1.1 Actuator Configuration

For Datalink users: actuator setup is done through the Parameters tab of each actuator interface.

By default i7X00 actuators are factory-configured as a port engine actuator. **Before installing the cables** and adjusting the actuator parameters you must designate the starboard actuator. Each actuator has a shift and throttle component that must also be configured as push or pull.

Procedure:

1. On the CANtrak display, navigate to **Dealer Menu > Initial Setup > System > Select Device Locations**.
2. Find the actuators in the list of devices. Compare the serial numbers with the actuators and use the **+** and **-** buttons to change the starboard actuator's configuration to Stbd.
3. Press **Save** and then exit the screen. You will be prompted to cycle system power to save the changes.
4. Navigate to **Dealer Menu > Initial Setup > Shift & Throttle** to get to the Shift & Throttle Setup menu (figure 4-1).




Figure 4-1. Shift and throttle setup screen.

NOTICE

See table 4-1 at the end of this section for typical actuator parameters. This information is provided for reference only, and should be verified before use.

- For each shift actuator set the Shift to Forward Direction parameter (figure 4-2) to Push or Pull to match the direction the actuator is required to move to engage *forward* gear. Don't adjust the other parameters yet.




Figure 4-2. Shift setup screen.

- For each throttle actuator set the Acceleration Direction parameter to Push or Pull to match the direction the actuator is required to move to *increase* throttle.




Figure 4-3. Throttle setup screen.

- Remove the actuator covers if you haven't already done so.
- Move the port and starboard control head levers to the forward and reverse gear positions and verify that the shift actuators move accordingly. Confirm that the control levers are controlling the correct actuators. If not, revisit step 2.

9. Increase the throttle on each of the control head levers from idle to full throttle and check that the throttle actuators advance and return accordingly. Place both levers back in the neutral position.
10. Apply the manual override decals (figure 4-4) to the actuator chassis label in the dashed boxes provided (figure 4-5).
 - a. Use 'Starboard' and 'Port' to indicate which actuator controls which engine.
 - b. Place the 'Idle' and '+' decals on the throttle actuators to indicate which direction moves the throttle to idle and which direction increases throttle.
 - c. Place the 'R' and 'F' decals on the shift actuators to indicate the shift direction for each gear.
11. Exit the setup. You will be prompted to cycle the system power to save the changes.
12. At this point you need to install the actuator cables. See the i7X00 Installation Manual.

STARBOARD ENGINE THROTTLE	STARBOARD ENGINE THROTTLE	
STARBOARD ENGINE SHIFT	STARBOARD ENGINE SHIFT	
CENTER ENGINE THROTTLE	CENTER ENGINE THROTTLE	R
CENTER ENGINE SHIFT	CENTER ENGINE SHIFT	
PORT ENGINE SHIFT	PORT ENGINE SHIFT	F
PORT ENGINE THROTTLE	PORT ENGINE THROTTLE	
STARBOARD	PORT	IDLE +

Figure 4-4. Actuator decal sheet.




Figure 4-5. Override decal locations (shaded).

4.1.2 Actuator Adjustment

NOTICE

See table 4-1 at the end of this section for typical actuator parameters. This information is provided for reference only, and should be verified before use.

⚠ DANGER

THIS PROCEDURE REQUIRES TURNING A PROPELLER BY HAND WITH THE IGNITION ON. USE EXTREME CAUTION.

NOTICE

It is not uncommon to have a longer actuator stroke length for the push direction gear. The difference is more pronounced with longer cables.

After installing the cables, proper adjustment is critical for overall system performance. This section will describe how to adjust the shift and throttle cables. Be sure to review and understand the installation goals for each section before proceeding.

4.1.2.1 Shift Adjustment

Successful installation and adjustment of the shift cables should accomplish the following goals:

- To have shift cables adjusted so the neutral position of the actuator represents the neutral position of the engine shift linkage.
- To set the stroke length to achieve full engagement of gear without interfering with the physical shift linkage limit.
- To have both gears fully disengage when returned to neutral.

Procedure

1. Turn ignition on but *do not* start engines.
2. Navigate to **Dealer Menu > Initial Setup > Shift & Throttle > Adjust Port Shift Actuator**.
3. While an assistant spins the port engine prop by hand, use the control lever to put the port engine into forward gear. Check that the gear engages fully.
4. If the gear does not fully engage, increase the Forward Stroke Parameter by 1mm at a time, press **Save**, and repeat the test until gear engagement is satisfactory.
5. Repeat steps 3 and 4 in reverse gear, this time adjusting the Reverse Stroke parameter.
6. Verify that the engine returns to neutral properly from both forward and reverse gear. The propeller must freewheel in neutral. If it doesn't, adjust the actuator-side rod end until the neutral position is correct.
7. Tighten the rod end lock nut (refer to the i7X00 installation manual). You will need to apply Loctite® 242 to the threads, but you will do this after verifying performance in the sea trial.
8. Repeat this procedure for the starboard shift actuator.

4.1.2.2 Shift Adjustment

Successful installation and adjustment of the throttle cables should accomplish the following goals:

- To have throttle cables adjusted evenly so the engines start to rev up at the same time given the same throttle (lever) position.
- To have the throttle always return to idle when the lever(s) are moved to idle.
- To have minimal lever travel before engines rev up.
- To set the stroke length so that wide open throttle (WOT) is achieved without unnecessary throttle cable movement.

Procedure

1. Turn ignition on but do not start engines.
2. Navigate to **Dealer Menu > Initial Setup > Shift & Throttle > Adjust Port Throttle Actuator.**
3. Increase the port control lever to the full throttle position (forward gear) and verify that the throttle linkage reaches the wide open throttle (WOT) position.
4. Increase the stroke parameter as necessary to reach the WOT position. Press **Save** after each adjustment to have it take effect.
5. Tighten the rod end lock nut (refer to the i7X00 installation manual). You will need to apply Loctite® 242 to the threads, but you will do this after verifying performance in the sea trial.
6. Repeat this procedure for the starboard throttle actuator.
7. The Idle Offset parameter is used to fine tune throttle response and to synchronize the throttle actuation.
 - a. On some engines it may take a large amount of lever travel before RPM starts to increase. You can reduce this deadband by increasing the Idle Offset parameter or by adjusting the rod end position.
 - b. When both levers are advanced at the same time both engines should start to increase RPM simultaneously. If they do not you can adjust the Idle Offset parameter until they are synchronized.

	EVINRUDE	HONDA	MERCURY	SUZUKI	YAMAHA	YANMAR
SHIFT SETTINGS						
Shift to Forward	Pull	Pull	Pull	Pull	Pull	Varies
Forward Stroke	32	32	34	34	32	32
Reverse Stroke	32	32	34	34	32	32
THROTTLE SETTINGS						
Acceleration Direction	Push	Push	Pull	Push	Push	Pull
Throttle Stroke	62	62	58	70	52	54

Table 4-1. Typical settings for mechanical engines. Verify before use.

4.2 Control Head Setup

For Datalink users: control head parameters are found on the Configuration tab of the Control Head interface.

The i7X00 EST system provides a number of control head parameters, listed in table 4-2. User parameters are marked with a (U) but they are not available to the user unless enabled as shown in section 5.7.1.

Control head parameters are adjusted from the CANtrak display at **Dealer Menu > Settings > Shift and Throttle**.

PARAMETER NAME	DESCRIPTION	RANGE	DEFAULT VALUE
Station Protection	When this parameter is enabled a specific sequence of button presses on the control head is required in order to take control of the shift and throttle. Refer to the User Manual for additional information on this feature.	Off or On	Off
One Lever Sync Mode (U)	Controls the throttle behavior when the Power Train Sync (PTS) mode is engaged. When set to RPM the software will use engine RPM feedback to match engine speeds. When set to the Throttle the control system will simply match the throttle command.	Off or On	Off
Two Lever Sync Enabled (U)	When this parameter is enabled the control system will synchronize engine speeds when both levers are in close to the same position. This feature requires engine RPM feedback.	Off or On	Off
Two Lever Sync Window (U)	The maximum throttle position difference for which Two Lever Sync will function.	1 to 10	5
Max Shift RPM	The maximum engine RPM at which a gear shift will be attempted. It is designed to delay gear shifts until the engine reaches a safe shifting speed.	100 to 2000	1500
Shift Proportional Delay Max	When there is no engine RPM source, this is the shift delay added by the control system when the control lever has been at 100% throttle for some time and is rapidly moved to another gear. In operation the shift delay is reduced in proportion to the amount of throttle commanded. We recommend you leave this parameter at the default of 5 seconds, but if the shifting is sluggish it can be reduced in small increments.	0 to 10	5
Shift Proportional Delay Gain	A multiplier applied to the Shift Proportional Delay Max time to control the shift delay.	0.1 to 1.0	0.5
FWD Throttle Curve (U)	There are two throttle curves that control the response characteristics when the control lever is at or near idle and in forward gear. Curve 1 is the default curve and is suitable for most applications. Curve 2 requires more lever travel before throttle increases.	Curve 1 or Curve 2	Curve 1
REV Throttle Curve (U)	There are two throttle curves that control the response characteristics when the control lever is at or near idle and in reverse gear. Curve 1 is the default curve and is suitable for most applications. Curve 2 requires more lever travel before throttle increases.	Curve 1 or Curve 2	Curve 1
FWD Trolling Max Throttle (U)	The maximum percentage of wide open throttle when trolling mode is engaged in forward gear. A setting of 50% means that when the throttle lever is fully forward the throttle is limited to 50% of maximum. This provides greater throttle sensitivity when moving at slow speeds.	5 to 100	50
REV Trolling Max Throttle (U)	The maximum percentage of wide open throttle when trolling mode is engaged in reverse gear.	5 to 100	100
Shift Fixed Delay	This is a Yanmar-specific parameter that delays shifting into the opposite gear when engine RPM feedback is not available. It will hold the transmission in neutral for the specified in time before shifting.	0 to 10	1

Table 4-2.

5.0 SEA TRIAL

⚠ WARNING

ALWAYS WEAR A PFD AND CONNECT THE ENGINE LANYARD(S) TO THE OPERATOR DURING SEA TRIAL.

⚠ WARNING

PROCEED CAREFULLY TO DEEP, OPEN WATER TO CONDUCT SEA TRIAL.

Before conducting this sea trial:

- check that both engines shift correctly into forward and reverse gear, and that they respond to throttle inputs.

5.1 Shift Performance

Check that both engines engage gears properly in both forward and reverse, and that they hold in gear under load. Check that they shift correctly into neutral. If necessary, repeat some or all of the shift actuator adjustment in section 4.2.3.

5.2 Throttle Performance

Check that both engines can reach wide open throttle RPM, and that both return to idle properly. Check that the amount of lever travel before RPMs begin to increase is acceptable. Move both levers forward together and check that the RPMs on both engines begin to increase at the same time. If necessary, repeat some or all of the throttle actuator adjustment in section 4.2.3.

Some engine models have sensitive off-idle performance, and may increase RPM quickly with a small movement of the levers from the idle position. The control head has an optional throttle curve that can slow this response if necessary. See section 4.3.

5.3 Control Head Adjustments

During the sea trial you should test the control head features. See the Quick Reference card for instructions.

The control head has adjustable lever friction and adjustable shift detents. Check that the feel of both levers is the same as you shift into and out of gear, and as you increase throttle. Use the adjuster screws on the back of the control head to make any necessary adjustments (see section 4.3.1).

On multi-engine boats engage the Power Train Sync feature and check that engine speeds are matched. If the Sync performance is unsatisfactory you may need to add an engine RPM source. See section 3.6.

Enter Trolling Mode and check that full throttle gives a satisfactory fraction of maximum, and that the low speed control is precise. Adjust the Trolling Max Throttle parameters (section 4.3) if necessary. If there are two control stations, run the vessel from both. Transfer control between control heads and verify that transfer works as it should. If you can't transfer control, check that the Station Protection feature is not enabled.

5.4 Conclusion of Sea Trial

Once you are satisfied with the shift and throttle performance the sea trial is complete.

After returning the vessel to port, check that none of the electrical harnesses and wiring are exposed to water, excessive temperatures, or mechanical damage. Check that all wire splices are properly secured, sealed, and dry. Check that all unused CAN connectors are properly sealed with sealing plugs.

You must also properly secure the actuator adjustment jam nuts (section 4.2):

- Remove the cable access covers.
- Loosen and back off the adjuster barrel jam nuts at the actuators.
- Apply a drop of Loctite Threadlocker Blue 242 to the threads adjacent to the adjuster barrel.
- Tighten the jam nuts against the adjuster barrels.
- Install the actuator cable covers. Be sure to install them to the correct actuator, because the labels that you applied during installation give manual override instructions specific to the actuator's type and instance

6.0 SYSTEM FAULTS & HAZARDS

Should a fault occur, it will be communicated to the user through the control head LEDs. Section 6.1 defines the types of hazards you may experience with the system and how the system will handle each.

NOTICE

When a serious fault occurs, consider your options. While the system has many features to allow the boat to return to port in a slow and safe manner, local conditions or operator skills may dictate that calling for assistance is the prudent thing to do.

6.1 Hazard Definitions

6.1.1 Danger

A danger fault is a critical system fault which will result in limited or no shift and throttle performance and requires immediate action.

Depending on the nature of the fault a variety of conditions might occur all designed to provide the safest situation for returning to port. Some examples are:

- Shift and throttle control may be unavailable for one or more engines.
- The shift and/or throttle may require manual override.

Indication

Dual lever control: both neutral indicator lamps will flash red quickly (5 times per second) until the levers are moved to neutral. When the levers are in neutral the red lamp will flash on the faulted side only.

Single lever control: Both the amber and green lamps will flash quickly.

6.1.2 Warning

A warning is a non-critical system fault which may cause the boat speed to be reduced.

Although a warning fault may not always adversely affect shift and throttle performance, it is an indication of a problem in the system and should be remedied. In some cases the fault can be reset by cycling the system power, but it may require attention from a certified technician.

Indication

Dual lever control: the blue Take Command lamp will flash quickly (5 times per second).

Single lever control: The amber lamp will flash quickly.

This page left intentionally blank.

7.0 WARRANTY

7.1 Statement of Limited Warranty

We warrant to the original retail purchaser that **Marine Canada Acquisition Inc. DBA SEASTAR SOLUTIONS** (herein forward referred to as SeaStar Solutions) products have been manufactured free from defects in materials and workmanship. This warranty is effective for two years from date of purchase, excepting that where **SeaStar Solutions** products are used commercially or in any rental or income producing activity, then this warranty is limited to one year from the date of purchase.

We will provide replacement product without charge, for any **SeaStar Solutions** product meeting this warranty, which is returned (freight prepaid) within the warranty period to the dealer from whom such product were purchased, or to us at the appropriate address. In such a case **SeaStar Solutions** products found to be defective and covered by this warranty, will be replaced at **SeaStar Solutions'** option, and returned to the customer.

The above quoted statement is an extract from the complete **SeaStar Solutions** products warranty statement. A complete warranty policy is available in our **SeaStar Solutions** products catalogue.

For more information please visit our website:

www.seastarsolutions.com/support-2/warranty-2/seastar-solutions-warranty

7.2 Return Goods Procedure

Prior to returning product to **SeaStar Solutions** under warranty, please call: **604-248-3858** or email: Marine.Warranty@seastarsolutions.com to obtain a return goods authorization number (claim number) and further shipping instructions.

7.3 Technical Support

Phone: 604-248-3858

email: seastar@seastarsolutions.com

Hours: Monday to Friday 05:00 – 15:30 PST

Web: www.seastarsolutions.com

Authorized Service Centers & Distributors

For a current listing of all our authorized service centers and distributors please visit our website: www.seastarsolutions.com

This page left intentionally blank.

APPENDIX A MOUNTING TEMPLATES

A.1 Control Head – Dual Lever

NOTICE

If you must photocopy this mounting template for use, check ALL measurements using a measuring device prior to using as a template.

SCALE = 1:1.




Figure A-1. Control head – Dual lever mounting template.



A.2 Control Head – Single Lever

NOTICE

If you must photocopy this mounting template for use, check ALL measurements using a measuring device prior to using as a template.

SCALE = 1:1.




Figure A-2. Control head – Single lever mounting template.



A.3 Actuator – Dimensions

NOTICE

This drawing is **NOT a template**. It is for informational purposes only.
 SCALE = 1:3.




Figure A-3. Acuator – Mounting dimensions. NOT A TEMPLATE..

A.4 Single Lever Interface – Dimensions

NOTICE

This drawing is **NOT a template**. It is for informational purposes only.

SCALE = 1:2.




Figure A-4. Single Lever Interface – Mounting dimensions. NOT A TEMPLATE.

APPENDIX B USING THE COLOR CANtrak DISPLAY

The color CANtrak is a powerful tool that can be used to set up the i7X00 actuators and perform software updates. Note that the CANtrak is used as a display on other products, so this section will describe functionality that will not be used for i7X00 setup.

B.1 Display Navigation

The five buttons at the bottom of the unit are used to select various actions. The five boxes at the bottom of the display screen will indicate the legend for each button. These legends vary based on what is on the screen.




Figure B-1. Navigation buttons and legend.

WORD OR SYMBOL	IDENTIFIES A FUNCTION OR SETTING
	Moves the cursor up the screen to the next item.
	Moves the cursor down the screen to the next item.
	Enters the sub-menu at the cursor location.
	Reduces the setting of the selected item.
	Increases the setting of the selected item.
OK	Accepts a given statement or condition and advances to the next screen.
	Returns to previous menu.
Save	Saves change and returns to previous menu.

B.2 Initial Startup




Figure B-2.




Figure B-3.

When the system power is turned on the CANtrak will display a splash screen, followed by an initial warning screen that prompts the user to perform a system inspection.

For new i7X00 systems it is normal when you turn on your system to get a number of warnings and alarms. These warnings exist because the system has not yet been fully configured and calibrated. Silence the buzzer by pressing Mute on the display. These alarms will go away during the setup procedure.

Press **Info** to step into the system inspection prompts, or press **OK** to continue. This will take you to the main run screen (also called the All Helms Active screen). If you press **Menu** from the main run screen you will see menus available to the user. (The screen shown is for an Optimus 360 system with joystick – on an EPS system you will not see the gear selection.)

Note: User functionality is not relevant when using the display as a setup tool for EST systems.

B.3 Unlocking the Dealer Menu




Figure B-4.

All setup and configuration tools are reached from the Dealer Menu, which authorized installers can access with a four digit PIN code (if you don't have a code contact SeaStar Solutions technical support). From the main run screen, press and hold **Menu** until you see the PIN entry screen.

Use the buttons to enter your four digit PIN code. Press the buttons briefly for digits 1-5, press and hold for digits 5-9.

If you enter the code incorrectly you will exit the screen and be placed into the user menu. Press and hold **Menu** again to get back to the PIN entry screen.

Once you have entered the correct code you will go directly to the Dealer Menu. You won't need to enter the code again unless you cycle system power.

NOTICE

The Dealer Menu can be unlocked when faults are active. Faults are suppressed during setup and system updates.

B.4 Menu Structure

The CANtrak display is built with smart menus. The options that are available to you will depend on the system type you set in the initial system setup. The menu structure is extensive, so rather than presenting a map of the entire structure we will highlight the key things you need to know.

Dealer Menu

The Dealer Menu is the base level menu for access to all of the setup tools. There are six submenus available from this screen.



Figure B-5.

Dealer Submenus

Shaded items are hidden on i7X00 systems.

INITIAL SETUP

1) System	Set system type, firmware update, set number of devices and their location, select RPM source.
2) Steering	Set cylinder types, purge and calibrate cylinders, set cylinder stroke limits.
3) Shift and Throttle	Adjust shift and throttle settings.
3) Yamaha EST Gateway	Configure EST gateway for Optimus 360 with Yamaha DEC engines.
3) Suzuki EST Gateway	Configure EST gateway for Optimus 360 with Suzuki SPC engines.
4) Joystick	Joystick tuning for Optimus 360.

SETTINGS

System	Control broadcast of RPM and gear selection on CAN3 (NMEA 2000)
Steering	Adjust steering parameters, such as helm effort and number of turns.
Shift and Throttle	Enable station protection and RPM sync, other settings. I7X00 EST only.
Yamaha EST Gateway	Yamaha DEC engines only.
Suzuki EST Gateway	Suzuki SPC engines only.
Joystick	Fine tuning for joystick control.
Display	Control user access to steering adjustments.

FAULTS

Shows all active faults. A yellow hazard triangle in place of the > arrow indicates that an active fault is present.

SYSTEM HEALTH

Displays each connected device with a status icon to indicate health.

DEVICES

Lists all devices. From submenu you can find product serial numbers, configure and calibrate the device, monitor inputs and outputs, update firmware, and export or import device settings.

TOOLS

Import and export system settings.

NOTICE

The Dealer Menu can be unlocked when faults are active. Faults are suppressed during setup and system updates.

B.5 First Time Service Tool Users

It is important for first time service tool users to set the system type to “Optimus EST”. This will prevent alarms and set the service tool for stand alone electronic shift and throttle. The service tool automatically configures menus to show only items that are relevant to your system.

1. Navigate to **Dealer Menu > Initial Setup > System > Select System Type**. Select “**Optimus EST**”.
2. Navigate to **Dealer Menu > Initial Setup > System > Select Shift and Throttle Type**. Select either **i7700** or **i6800** depending on your system. For i7800 system, use the i7700 selection.
3. Navigate to **Dealer Menu > Initial Setup > System > Select number of devices**. Set the number of control heads and engines.

NOTICE

Take note that when backing out of system menu(s) the service tool will prompt you to power cycle the system. Do this by turning system power off, then back on.

The service tool will require dealer pin code each time the system is power cycled.

Your Service tool is now ready to continue with setup in section 4.0.

APPENDIX C SETUP WITH DATALINK

Datalink is a software tool that can be used for system setup and configuration. Although most of these functions can be performed with the color CANtrak display, experienced users may find it quicker to use Datalink for these tasks.

C.1 Dealer Tools

To use Datalink with an i7X00 system you will need the following items, supplied with kit EPSK1206:

- IXXAT USB to CAN converter, part #214720
- Programming harness, 6-pin FCI to serial, part #CM21010
- Programming harness, DeviceNet to serial, part #CM21106

You will also need a Windows®-compatible notebook computer with Datalink installed on it. See Appendix D for information on how to download and install the latest version of the software.

C.2 Connection

NOTICE

Always make sure the latest version of Datalink is installed and in use. Check www.optimusdealers.com for latest program revision.

Procedure

1. Connect the notebook computer to an unused CAN2 network port using the CAN2 programming harness as shown in figure C-1. If necessary an additional tee may be installed but *must* be removed or capped after use. If the spare tee is left in the system, there must still be one (and only one) terminator at each end of the CAN2 bus.
2. Turn on the notebook computer and open the Datalink program located on the desktop.
3. Once Datalink opens, the Interfaces section of the Workspace should become populated with components connected to the network. If not, double click on Optimus CAN2 in the protocols section. The components should turn green as communication is established. See figure C-2 to familiarize yourself with the Datalink workspace.
4. Double-clicking on any of the components will enter the configuration pages for that particular component.
5. Before proceeding with the setup, verify that the firmware revisions are up to date for each of the components. Refer to Appendix D for instructions on checking and updating firmware revisions.




Figure C-1. Dealer Kit connection.

C.3 Navigating Datalink

When you run the Datalink software it will open up with a window similar to the one shown in figure C-2.

At the very top of the display is a series of pull-down menus that access various functions. Just below that is the toolbar, which contains buttons for the most commonly used functions.

The pane on the left is called the Workspace. It is your primary access point to the devices in your system. At the top of the workspace is a list of available Interfaces; these are the devices on the network defined by the selected protocol. In the figure you can see under Protocols that 'Optimus CAN2' is highlighted, so the list of Interfaces is a list of devices connected on the CAN2 network.




Figure C-2. Datalink Workspace. Your available interfaces may not be exactly as shown.

Double click on a device in the Interfaces list to open the configuration page for that device. Click Workspace in the toolbar at any time to bring up the **Workspace** window.

Important notes about Datalink

Datalink is not like most software packages you are used to. Unlike a word processor, you don't open a file, make changes, and save them. Instead, you open an Interface, which is actually a database that is specially formatted on your screen. The parameter fields (any box with editable values) are cross-referenced to data tables in the devices, but it is not in real-time.

What this means is that the parameters you see are just a snapshot of what is in the device. If you edit these parameters on screen, the changes exist only in Datalink. They will not exist in the device until you click the **Write** button on the toolbar. **Write** takes all the database values that exist in Datalink and copies them to the device, where they are saved in nonvolatile memory (i.e. memory that is not lost when power is removed).

Similarly, clicking **Read** will copy parameters from the connected device into the Datalink database, allowing you to see the current state of the actual device. This is a good way to check that any changes you make have been correctly copied to the device.

For this reason, you will generally not need to use the **Open** and **Save** buttons on the toolbar. They have a different function in the context of Datalink, and aren't used for editing parameters. Likewise, if you are prompted to save changes when you close an Interface, just click **No** and exit. The save function has nothing to do with whether the changes are saved on your device.

C.4 Actuator Setup

C.4.1 Step 1 – Actuator Configuration Using Datalink

This step will establish communication between the shift and throttle actuators and Datalink and will configure the shift and throttle actuator settings. From the factory, all actuators default to being Port Shift actuators. This section will assign the correct function to each of the actuators.

⚠ CAUTION

Ensure mechanical cables are not connected to the actuators at this point.

Procedure

1. In the Datalink workspace you should see two Port Shift Actuators for each engine, as shown in figure C-3 below. Click on the + beside an actuator to view the part and serial number information associated with it.




Figure C-3. Shift/Throttle actuator configuration.

1. Match the serial number shown with the serial numbers you recorded in section 3.3.1. You now know the type (shift or throttle) and the instance (port or starboard) of the actuator. Double-click the actuator to open its configuration file.
2. Open the Parameters tab.
3. Set the Actuator Type and Actuator Instance parameter as required. (See figure C-4.) In a single-engine application set the instance for both actuators to Port.
4. Set the type-specific parameters as follows:
 Throttle actuators: Set the Throttle Acceleration parameter to Push or Pull for the direction the throttle actuator is required to move to *increase* throttle.
 Shift actuators: Set the Shift to Forward parameter to Push or Pull for the direction the shift actuator is required to move to engage *forward* gear.
5. Click **Write** to save the changes. The strokes and throws will be set in section C.4.3 after the cables have been installed.
6. Repeat items 1 through 6 for each actuator.
7. Remove cable access covers (See figure C-5) on all actuators. DO NOT connect mechanical cables at this point.
8. With the covers removed, move the port and starboard control head handles to the forward and reverse positions and verify that the shift actuator racks both move accordingly.
9. Increase the throttle on each of the control head handles from idle to the full throttle positions and verify that the throttle actuator racks advance and return to idle accordingly.
10. Apply manual override direction decals as shown in section 4 (figure 4-9 and figure 4-10).

Dealer	
Actuator Type:	Shift
Actuator Instance:	Port
Throttle Acceleration:	Pull
Shift To Forward:	Push
Throttle Offset:	8.0 mm
Throttle Stroke:	60.0 mm
Shift To Forward Throw:	34.0 mm
Shift To Reverse Throw:	34.0 mm
Neutral switch connected	<input checked="" type="checkbox"/>

Figure C-4.




Figure C-5. Actuator cover removal and location of serial number.

C.4.2 Step 2 – Cable Installation and Adjustment

Refer to section 4.2.2 for instructions on the mechanical installation of the cables.

C.4.3 Step 3 – Final Setup and Actuator Adjustment

SHIFT

Successful installation of the shift cables should accomplish the following goals:

- To have shift cables adjusted so neutral position of actuator represents neutral position of engine shift linkage.
- To set the stroke length to achieve full engagement of gear yet not interfere with physical shift linkage limit. (Done in Step 4 below.)
- To have both gears fully disengage when returned to neutral.

⚠ DANGER

THIS PROCEDURE REQUIRES TURNING A PROPELLER BY HAND WITH THE IGNITION ON. USE EXTREME CAUTION.

Procedure

1. Turn ignition on but *do not* start engines.
2. Open the port shift actuator in Datalink.
3. With an assistant spinning the prop by hand, put the port engine into forward gear and verify that the gear engages.
4. Increase the Shift to Forward Throw value 1 mm at a time as necessary to fully engage the gear. Click **Write** to save each change.
5. Repeat items 3 and 4 for reverse gear, modifying the Shift to Reverse Throw value as necessary to fully engage the gear.

⚠ DANGER

THIS PROCEDURE REQUIRES TURNING A PROPELLER BY HAND WITH THE IGNITION ON. USE EXTREME CAUTION.

6. Verify that the engine returns to neutral properly from both forward and reverse gear. The propeller must freewheel in neutral. If it doesn't, adjust the actuator side adjustment barrels until the neutral position is correct. (See Section 4.2.2.1 for adjustment.)
7. Repeat items 2 to 6 for the starboard shift actuator if applicable.
8. Tighten the actuator side lock nut (see figure 4-13) for the shift actuators. Once the final adjustments are made you will need to apply Loctite® 242 to the threads, but you will do this after the sea trial.
9. If your engine already has start-in-gear protection you can uncheck the box labeled "Neutral switch connected."

NOTICE

It is not uncommon to have stroke length a little longer for the push direction gear to take up the lost motion of the cable in the push direction. This is more pronounced with longer cables.

THROTTLE

Successful installation of the throttle cables should accomplish the following goals:

- To have throttle cables adjusted evenly so engines *start* to rev up at the same time given the same throttle (handle) position.
- That throttle always returns to idle when handle(s) are moved to idle.
- That there is minimal handle travel before engines rev up.
- That the stroke length is set to achieve wide open throttle (WOT) engine speed without unnecessary throttle cable movement.

Procedure

1. Turn ignition on, do not start engines.
2. Open the port throttle actuator in Datalink.
3. Increase the port throttle lever to the full throttle position and verify that the throttle linkage reaches the wide open throttle (WOT) position.
4. Increase the Throttle Stroke value in Datalink as necessary to reach the WOT position. Click **Write** to save each change.
5. Repeat items 2–4 for the starboard throttle actuator if applicable.
6. Tighten the actuator side lock nut (see figure 4-13) for both throttle actuators. Once the final adjustments are made you will need to apply Loctite 242 to the threads, but you will do this after the sea trial.
7. The Idle Offset parameter is used to fine tune throttle response and to synchronize the throttle actuation.
 - a. On some engines it may take a large amount of lever travel before RPM starts to increase. You can reduce this deadband by increasing the Idle Offset parameter, or by adjusting the actuator adjuster barrels (section 4.2.2.2).
 - b. When both levers are advanced at the same time both engines should start to increase RPM simultaneously. If they do not you can adjust the Idle Offset parameter (or the actuator adjuster barrels) until they are synchronized.

⚠ WARNING

AFTER FINAL ADJUSTMENT IS MADE APPLY LOCTITE® 242 (BLUE) AND TIGHTEN JAM NUT ON ACTUATOR SIDE.

C.5 Control Head Setup

The control head has several configurable parameters, as shown in figure C-6 below. The default settings will generally provide excellent performance for most boats.

Access the parameters by double-clicking on the Main Control Head in the Datalink interface list, then clicking on the Parameters tab. A reset function is provided so that default values can be restored at any time. Remember to click **Write** after making any changes.




Figure C-6. Control Head setup.

The functions of these parameters are as follows:

One Lever Sync Mode – Controls the throttle behavior when the Power Train Sync (PTS) feature is engaged. When set to RPM the control system will use engine RPM feedback to match engine speeds. (An engine RPM source is required – see section 3.6.) When set to Throttle the control system will simply match the throttle command.

Two Lever Sync Enabled – When Two Lever Sync is enabled the control system will synchronize engine speeds when both levers are in close to the same position. This feature requires an engine RPM source (see section 3.6).

Two Lever Sync Window – This parameter sets the maximum throttle difference for which Two Lever Sync will function.

Forward/Reverse Trolling Mode – sets the maximum percentage of wide open throttle when trolling mode is engaged. A forward setting of 50% means that when the throttle lever is fully forward the throttle is limited to 50% of maximum. This provides greater throttle sensitivity when moving at slow speeds.

Forward/Reverse Throttle Curve – There are two throttle curves that control the response characteristics when the control lever is at or near idle. Curve 1 is the default curve, and is suitable for most applications. Curve 2 requires more lever travel before throttle is increased.

Station Protect – When enabled (Yes), this feature prevents accidental switching between control stations on multi-station boats by requiring a specific sequence of button presses. Refer to Book 70– i7X00 User Manual for more information.

Control Head Instance – If you are setting up a second station, change this parameter to Second.

Shift and Throttle Type – Ensure this parameter is set to SeaStar i7X00.

APPENDIX D UPDATING FIRMWARE

NOTICE

This section contains instructions for i7X00 Shift and Throttle System, Optimus EPS and Optimus 360 systems.

From time to time it may become necessary to update the Datalink notebook software and the i7X00 component firmware as new versions become available.

Check www.optimusdealers.com for latest available firmware. The updates are packaged in a single download file called 'Optimus and Optimus 360 Datalink Updater Version X', where X indicates the revision. A readme file describes the nature of the updates, the component revision files included in the package, and any special instructions. **ALWAYS** read the readme file prior to updating. The readme file can be accessed from the Datalink 'Help' menu. Click 'Help,' then click 'readme.txt' to view the file.

When run, the Updater will first install the latest version of Datalink on your computer, then automatically load the latest firmware files to the notebook computer and put them in the [Desktop\Optimus Firmware] folder. Each component update file will be in a separate folder with the component name. See Figure D-1.

Name	Date modified	Type
Actuator Shift_Throttle	4/15/2013 11:00 AM	File folder
CANTrak	4/15/2013 11:00 AM	File folder
Control_Head	4/15/2013 11:00 AM	File folder
EPS_Helm	4/15/2013 11:00 AM	File folder
EST	4/15/2013 11:00 AM	File folder
Joystick	4/15/2013 11:00 AM	File folder
PCM	4/15/2013 11:00 AM	File folder

Figure D-1. Desktop\Optimus Firmware – Folder Structure.

NOTE: The installer only loads the required files to the computer; it does NOT perform the actual component updates. Refer to section D.2 for detailed component updating instructions.

D.1 Checking Component Firmware Revision Levels

The current firmware version installed in a component can be checked through Datalink.

NOTE: When opening component windows in Datalink, it is good practice not to have more than two components open at a time to avoid potential communication errors.

D.1.1 Using DATALINK

1. Connect the computer to the i7X00 system as shown in section C.2.
2. In the 'Interfaces' section in Datalink, click on the  box to expand the component information. See figure D-2. (In an i7X00 system you will see only the Control Head(s) and Actuators in the component list.)
3. Firmware revision can be found under the 'Firmware Part Number' field.




Figure D-2. Datalink workspace.

D.2 Updating Actuators and Control Head

NOTICE

Please contact SeaStar Solutions Technical Support before attempting to update your system firmware. Not all new software releases will be compatible with your system. These instructions are provided for your information only, and assumes that you are updating your firmware under guidance.

Procedure

1. Navigate to www.optimusdealers.com and download the latest file updater package to the notebook computer's Desktop.
2. Double click on the updater to install the files on the computer.
3. Navigate to the readme file at [Desktop\Optimus Firmware] and check the readme file for any special instructions.
4. Connect the notebook computer to the system and open Datalink as outlined in section C.2.
5. Double click on the component to be updated to enter the configuration pages for that particular component.



Figure D-3. Top Toolbar.

6. Select 'Update' on the top toolbar. Click box 'select update file' & navigate to the appropriate update file in [Desktop\Optimus Firmware\Update Files]. Each update file will be located in a folder with the component names (see figure D-1). See table D-1 for component and file name cross reference.

Component	Update File
Actuators	SW0263Rev[].s19
Control Head	SW0262Rev[].s19

Table D-1. Update File Names.

7. Click 'Open' to begin the update process. A window will pop up asking if you are sure that you want to update. Click 'Yes'.
8. Once the update is complete, a popup box states that the new application was successfully loaded and to reset power to complete operation. Click 'OK' to close the control module update box and close Datalink.

NOTICE

Failure to close Datalink may result in some components not updating properly. Always close all components and the Datalink program after an update.

9. Key off all ignition switches for 2 to 4 seconds to power down the system.

10. Key on and power up the i7X00 system.
11. Reconnect to the system using Datalink. (It may take a moment for the components to become visible in Datalink)
12. Verify that the latest revision of firmware was loaded to the component as per Section D.1.
13. Repeat steps 5 through 13 for any other components which may require updating.

NOTE: In some cases, configuration values may need to be manually re-entered after an update. The readme files will instruct to do so if necessary so **ALWAYS** read the readme file prior to updating.

NOTE: When opening component windows in Datalink, it is good practice not to have more than two components open at a time to avoid potential communication errors.

NOTE: When updating components, it is common to have warning indications on the control head. These can be ignored, but no active faults should be present after completion of the updating process.

D.3 Updating the CANtrak Software

The CANtrak software can only be updated from the display. You will need a USB drive (preferably empty) and a computer to perform the update.

Procedure

1. If you haven't already done so, download and install the file updater (page D-1).
2. Find the Optimus Firmware folder on your desktop and open it, then open the Color CANtrak folder.
3. In the Color CANtrak folder you will find a .zip file. Double-click on it to view the files in the folder.
4. Copy all the files to the root level of your USB drive. Don't put them in a file folder.
5. Plug the USB drive into the port on the back of the CANtrak. If your system is off, turn it on now.
6. The software update process is automatic. When prompted, remove the USB drive from the display. The display will reboot into the updated software version.
7. Delete the files you copied to the USB drive. If you don't, you won't be able to use the USB drive for other CANtrak functions.

© 2017 MARINE CANADA ACQUISITION INC.
DBA SEASTAR SOLUTIONS

PRINTED IN CANADA 08/19

Please scan
this QR code
and watch our
latest **Boating
Safety** video.



SEASTAR SOLUTIONS
3831 NO.6 ROAD
RICHMOND, B.C.
CANADA V6V 1P6

FAX 604-270-7172

www.seastarsolutions.com

ISO 10592



FORM NO. 710351 REV. C

