





AA150.1: WINDLASS CHAIN ONLY WIRING FOR AA150 SYSTEM



WARNING: Power must be disconnected during installation and when making any changes to wiring after installation

INSTALLATIONS MUST BE CARRIED OUT IN ACCORDANCE WITH USCG, ABYC, NMMA and BWEA REQUIREMENTS