
AA150.2: WINDLASS ROPE AND CHAIN WIRING FOR AA150 SYSTEM





WARNING: Power must be disconnected during installation and when making any changes to wiring after installation

INSTALLATIONS MUST BE CARRIED OUT IN ACCORDANCE WITH USCG, ABYC, NMMA and BMEA REQUIREMENTS

150.2/06/2010